

Calcium Remover

serves to remove stubborn calcium deposits from rollers and blankets.

Hard water and paper coating residues often leave behind annoying calcium deposits. Calcium Remover provides for fast, thorough and pore-deep removal. The original positive ink transfer properties are restored.

Safety notes:

- Irritates the eyes and skin
- Flash point not applicable
- Free of chlorinated hydrocarbons and aromatic compounds

Tips for use:

- Apply Calcium Remover evenly over the rollers after normal roller washing
- Run the rollers to allow the cleaner to act
- Subsequently rinse generously with water – use a roller washing program with a high water component
- In case of particularly stubborn deposits, allow to act for longer or repeat the process!
- Store in a dry and cool place
- Protect Calcium Remover against frost

Important:

In regions with hard water and when using lower-quality substrates, we recommend using Calcium Remover at least once per week.

Packaging:

Calcium Remover is supplied in 1-litre disposable bottles.

Further information

Please refer to the label and product safety data sheet.



KBA (UK) Ltd.

5 Century Court, Tolpits Lane, Watford, Hertfordshire WD18 9PX
 Phone (direct line): 01923 810397 | Fax: 01923 213411
 Email: consumables@kba-uk.com | Web: www.kba.com/gb/press-consumables